

AMPIRE

CPR60 MCU-Update

20260207_1521

Computer

- 1) Speichern Sie die Datei „LTTMcu.bin“ auf einen leeren USB 2.0 Stick.
- 2) Machen Sie einen Rechtsklick auf das USB-Laufwerk und wählen „Auswerfen“. Anschließend ziehen Sie den USB-Stick aus dem Computer.


CPR60

- 3) Schalten Sie das Gerät ein.
- 4) Stecken Sie den vorbereiteten USB-Stick in das USB-Kabel des CPR60.
- 5) Das Update-Fenster öffnet sich. Tippen Sie auf „MCU Update“.



- 6) Nach dem Update startet das CPR60 automatisch neu. Entfernen Sie den USB-Stick. Fertig.

Die neue MCU-Version wird wie folgt angezeigt:



Änderungsprotokoll

Die Funktionen der Werkseinstellungen wurden erweitert.

AMPIRE

CPR60 MCU-Update

20260207_1521

Computer

- 1) Save the file "LTTMcu.bin" to an empty USB 2.0 flash drive.
- 2) Right-click the USB drive and select "Eject." Then, remove the USB drive from your computer.


CPR60

- 3) Turn on the device.
- 4) Insert the prepared USB flash drive into the CPR60's USB cable.
- 5) The update window will open. Tap "MCU Update".



- 6) After the update, the CPR60 will restart automatically. Remove the USB flash drive. Done.

The new MCU version will be displayed as follows:



Change Log

The functions of the factory settings have been expanded.