



BMW (NBT-EVO-MGU) WIRING DIAGRAM--LDS-NBT-MINI/LDS-EVO-MINI/LDS-MGU-MINI



DIP SWITCH SETTING

After changing the dip code, press reset or power on again

PIN1	OFF/ON	NBT10.25" & 8.8" / NBT6.5"
PIN2	OFF/ON	NG/EVO 6.5"
PIN1,2	OFF/ON	NG/EVO 8.8"
PIN1,3	OFF/ON	NG/ EVO 10.25"
PIN2,3	OFF/ON	NG/MGU 12.5"
PIN4	OFF/ON	NG/NG
PIN5	OFF/ON	NG/NG
PIN6	OFF/ON	NG/NG
PIN7	OFF/ON	NG/Touch point coordinate correction, then turn "OFF"
PIN8	OFF/ON	NG/NG



Remark:
Pls keep in the original AUX interface when switch to CarPlay interface



Long press MENU or BACK to switch CarPlay, long press again to exit CarPlay;
Short Press MENU to activate "Siri";
iDrive Knob to control up/down/left/right/ok.

