



BENZ (NTG4.5/4.7&NTG5.1/5.2/5.5) WIRING DIAGRAM--LDSNTG45-MINI/LDS-NTG50-MINI



NTG4.5/4.7 DIP SWITCH SETTING

(After changing the dip code,press "reset"or power-on again)

DIP S/W	Status	Description
PIN1	OFF / ON	7inch (800*480) / 5.8 inch (480*234)
PIN2	OFF / ON	NG/NG
PIN3	OFF / ON	NG/NG
PIN4	OFF / ON	NG/NG
PIN5	OFF / ON	NG/NG
PIN6	OFF / ON	NG/NG
PIN7	OFF / ON	NG/NG
PIN8	OFF / ON	NG/NG

NTG5.1/5.2/5.5 DIP SWITCH SETTING

(After changing the dip code,press "reset"or power-on again)

DIP S/W	Status	Description
PIN1, 2	OFF / ON	15-18 C class 7 inch / 15-17 S class 12.3 inch
PIN2, 3	OFF / ON	NG/15-17 S class 12.3 inch with other parameters
PIN1	ON	15-18 year,all BENZ models with 8.4inch monitor
PIN2	ON	15-18 A/B/E/CLA/GLE class with 7 inch monitor
PIN4	OFF / ON	NG/NG
PIN5	OFF / ON	NG/NG
PIN6	OFF / ON	NG/NG
PIN7	OFF / ON	NG/NG
PIN8	OFF / ON	NG/NG

REMARK:Please keep in the AUX interface when switch the CarPlay interface



- 1) Long press and hold "BACK"button to switch MENU,short press"BACK"button again,exit MENU.
- 2)Short press "C" or " "button to open "Siri".
- 3) Knob to control up/down/right/left/ok.