


# VW Touareg (8 inch) WIRING DIAGRAM---LDS-VWT80-MINI



Remark:Different year's car with different cable color of CD headunit's PIN10

## DIP SWITCH SETTING

(After changing the dip code,press "reset"or power-on again)

DIP S/W	Status	Function
PIN1	OFF / ON	NG/NG
PIN2	OFF / ON	NG/Touch point coordinate correction,then turn"OFF"
PIN3	OFF / ON	NG/NG
PIN4	OFF / ON	NG/NG
PIN5	OFF / ON	NG/NG
PIN6	OFF / ON	NG/NG
PIN7	OFF / ON	NG/NG
PIN8	OFF / ON	NG/NG



- REMARK:**Please keep in the AUX interface when switch the CarPlay interface (If there is no AUX status,pls activate it by computer)
- 1) Long press and hold "NAV" button to switch MENU, long press"NAV" button again,exit the switch MENU.
  - 2)Other functions use touch screen to control it.