[en]=> U122_50_10					
Legend:					
	Volume up		Volume down	Δ	UP
$oldsymbol{ abla}$	DOWN		RIGHT	4	LEFT
N	FFW	M	RRW	KK	SEEK
M	TRACK	VOL PUSH	VOL/PUSH	W	FRONT GLASS HEATING
444	REAR GLASS HEATING		STERING WEEL HEATING		HEATING SEAT DRIV.
PATE	HEATING SEAT PASS.		VENTILATION SEAT DRIV.		VENTILATION SEAT PASS.
GEAR+	HIGHER GEAR	GEAR-	LOWER GEAR		4WD AUTO
4WD LOCK	4WD LOCK	4WD LOW	4WD LOW		2WD
	SUSPENSION UP		SUSPENSION DOWN		SUSPENSION MODE
	STEERING MODE	P	CLOSED CIRCUIT	%	INCREASE FAN
%	DECREASE FAN	نرد	FAN MODE	+	INCREASE TEMPERATURE
	DECREASE TEMPERATURE	SET	SET TIRE PRESSURE		PARK ASSIST
	LANE ASSIST		PARKTRONIC OFF	***	WEBASTO
OFF	ESP_OFF	i-stop OFF	i-stop OFF	A	AUTO START/STOP
	RVM	LC	LC	A/C	A/C
CLIMATE	CLIMATE	AFS OFF	AFS OFF	(SPORT)	SPORT
(NORMAL)	NORMAL	(ECO)	ECO	HEIGHT HIGH	HEIGHT HIGH
SNOW	SNOW	SRC	SRC	TOUR	TOUR
READ	READ	RESET	RESET	MODE	MODE
ENTER	ENTER	VIEW	View	OK	OK
HOME	НОМЕ	AUTO	AUTO	ESC	ESC
OFF	OFF	BACK	ВАСК	LIST	LIST
MEM	MEM	NAVI	NAVI	MAP	MAP
F	AUDIO	MUSIC	MUSIC	RADIO	RADIO
DISC	DISC/AUX	FM/AM	FM/AM	DISP	DISPLAY
TEL	TEL	MEDIA	MEDIA	SOURCE	SOURCE
info	INFO	MAIN	MAIN	ODO TRIP	ODO/TRIP
O _Q M	SEETING'S		MENU		MENU OUT
\bigcirc	Return		FOOTBRAKE		ACCELERATOR
A/T SW	THE STICK'S SWITCH OF THE AUTOMATIC TRANSMISSION	E/P	E/P		L
FL	FRONT LEFT DOOR WINDOW	FR	FRONT RIGHT DOOR WINDOW	RR	REAR RIGHT DOOR WINDOW

